



SF STAF STAD SPF SPPF SPPPF

SHF STHF


SAF
SAD
STF




V1




V2




V3




V4




B5/1




B4/1




B5/2




B4/2




B5/3



B4/3



B5/4



B4/4

Bei Bestellung Klemmkastenstellung (o, g, e, c) angeben.

Quote terminal box position (o, g, e, c) with order.

Veillez indiquer la position de la boîte à bornes (o, g, e, c) lors de la commande.